

# MIRRO

## Foley Stainless Steel Food Mill



### Important Safety Use and Care Information

Please read this guide before using your new Mirro Food Mill. These instructions are for your general safety. Please follow the use & care to avoid personal injury and damage to your Food Mill.

### Before First Use

Please Wipe off the Food Mill with a damp cloth before any initial use or when it has not been used for a long period.

### Learning about your Food Mill:



1. Removable crank handle
2. Bottomless Bowl
3. Thumb screw
4. Resting helper handle

### How to Use

- Insert removable cranking handle into bottomless bowl
- Secure cranking handle by the thumb screw located at the bottom
- Turn crank clockwise, pressing down. Reverse crank often.

### How to Clean

- Remove thumb screw, lift out crank assembly. Place under running water and dry.
- Hand wash with warm soapy water. Before storing, dry completely.

### Need Help?

#### How do you get service?

- Save your receipt as proof of date of purchase.
- Please DO NOT return the product to the place of purchase.
- For service, repairs, or product related questions, please call the number on this manual or contact us by email.
- Please DO NOT mail product back to manufacturer.

### What does it cover?

- Manufacturer defects in materials or workmanship (returns will only be accepted if due to a manufacturer defect and will not be accepted after 90-Day from date of purchase. Returns will only be accepted with original receipt).
- Applies only to products purchased and used in the United States, Hawaii or Alaska.

### Warranty does NOT cover:

- Damage from commercial use.
- Damage from misuse, abuse, or neglect.
- Products that have been modified in any way.
- Other accessory items that are packed with the unit.
- Damage due to accidents or repairs.

### 90-DAY LIMITED WARRANTY

Email: [customerserviceimusa@groupeseb.com](mailto:customerserviceimusa@groupeseb.com)  
or call 1-800-850-2501.

# MIRRO

## Molino de Alimentos de Acero Inoxidable



### Seguridad importante Información de uso y cuidado

Lea esta guía antes de usar su nuevo molino de alimentos Mirro. Estas instrucciones son para su seguridad general. Siga las instrucciones de uso y cuidado para evitar lesiones personales y daños a su molino de alimentos.

### Antes del Primer Uso

Limpie el molino de alimentos con un paño húmedo antes de cualquier uso inicial o cuando no se haya utilizado durante un periodo prolongado.

### Aprendiendo sobre su Molino de Alimentos:



1. Manivela extraíble
2. Cuenco sin fondo
3. Tornillo de mariposa
4. Mango auxiliar de reposo

### Como Usar su Molino

- Inserte la manivela extraíble en el recipiente sin fondo
- Asegure la manivela con el tornillo de mariposa ubicado en la parte inferior
- Girar la manivela en el sentido de las agujas del reloj, presionando hacia abajo. Marcha atrás a menudo.

### Limpieza

- Retire el tornillo de mano, levante el conjunto de manivela. Poner bajo agua corriente y secar.
- Lavar a mano con agua jabonosa tibia. Antes de guardar, seque completamente.

### ¿Necesitas ayuda?

#### ¿Cómo se obtiene servicio?

- Guarde su recibo con la fecha de compra.
- NO devuelva el producto al lugar de compra.
- Para servicio, reparaciones o preguntas relacionadas al producto, llame al número que se encuentra en la parte de atrás de este manual o contáctenos por correo electrónico.
- NO devuelva el producto al fabricante.

### ¿Qué cubre la garantía ?

- Defectos del fabricante en materiales o mano de obra (solo se aceptarán devoluciones si se deben a un defecto de fabricación y no se aceptarán después de 90 días a partir de la fecha de compra. Las devoluciones solo se aceptarán con el recibo original).
- Se aplica solo a productos comprados y usados en los Estados Unidos, Hawái o Alaska.

### Esta garantía NO cubre:

- Daños por uso comercial.
- Daños por mal uso, abuso o negligencia.
- Productos que han sido alterados de alguna manera.
- Otros accesorios empacados con el aparato
- Daños ocasionados por accidentes o reparaciones.

### GARANTÍA LIMITADA DE 90-DÍAS

Correo Electronico:

customerserviceimusa@groupeseb.com  
o llame 1-800-850-2501.